

Hejny Rentals, Inc.

Contractor, Lawn & Garden, and Party Equipment Rentals
1829 White Bear Ave. - Maplewood, MN 55109
Phone: 651-770-3841 – Fax: 651-770-1725
www.hejnyrental.com

TANDEM AXLE AND SINGLE AXLE HEAVY DUTY TRAILERS

TRAILERS CAN ONLY BE USED LOCALLY - 500 MILE LIMIT FROM STORE

VEHICLE REQUIREMENTS

- A. Tandem Axle trailers require a FULL SIZE 1/2 Ton Pick Up or larger truck. Dodge Dakotas and other SUV's do not meet the needed criteria and do not have large enough GVW's. Hejny Rental reserves the right to refuse the rental of a trailer at its discretion.
- B. Single Axle trailers require a SUV, rear wheel drive minivan, or larger truck with at least a 5000 lb. receiver hitch.

HOOK-UP

- A. Temporary hitches or clamp-on bumper hitches are not acceptable.
- B. Check to make sure hitch is secure and that bolts or welds are not loose.
- C. Always use the proper size ball. Loads greater than 5000 lbs. require a 2-5/16" ball or pintle hitch.
- D. Attach the safety chains so that they cross underneath the trailer tongue.
- E. Check the light wires to make sure they are in good condition (not frayed or broken) and have enough slack to allow for turning. Be sure the brake, turning, and running lights are operational. CUSTOMER IS RESPONSIBLE FOR WIRING AND LIGHTS ON TOWING VEHICLE.

LOADING

- A. DO NOT OVERLOAD TRAILER. Maximum load should be posted on trailer.
- B. Use the heaviest possible hitch for towing. A loaded trailer should never outweigh the towing vehicle. The towing vehicle must weigh at least 1000 lbs. more than the trailer weight combined with the load weight.
- C. Load the trailer so that 60% of the load is forward of the wheel assembly. This allows 10% of the load to rest on the hitch, and the remainder of the weight to be carried by the trailer.
- D. Make sure the load is secured in front and in back.

TOWING

- A. Start slowly, drive slowly, stop slowly - you are towing extra weight.
- B. If the trailer sways, pull to the side of the road as soon as possible, applying steady brake pressure until stopped. Determine the cause of the sway: Improper loading, Load shift, Loose hitch, Tire pressure (low or flat), Hub temperature (wheel bearings), or Broken springs.
- C. Be careful when backing up - use a spotter.
- D. When passing a slower vehicle, or parking, remember the extra length of your vehicle.
- E. With heavy loads, be careful when driving down steep grades.
- F. Do not transport passenger on/in a towed trailer.

WARNING! This trailer cannot be transferred or towed by a different vehicle!

Description of material or equipment being hauled: _____

Need It. Rent It!